

Pomembne varnostne informacije

Prva uporaba zobne ščetke lahko povzroči iritacije in krvavitve dlesni. To je normalen pojav, e dlesni raste.

⚠Warning

- Users undergoing orthodontic treatment, or users who have dental repairs or implants should consult their dentist or orthodontist before using this toothbrush.
- This toothbrush complies with the safety standards for electromagnetic devices. For any questions about using the device alongside pacemakers or other implanted devices, please consult a doctor or the manufacturer of the implanted device before use.
- This toothbrush is designed to clean teeth, gums, and tongue only. Do not use it for any other purposes. If you feel any discomfort or pain, stop using the toothbrush and consult your dentist.
- Do not immerse the charging dock in water or any other liquid.
- Do not plug the charging dock into an outlet when there is liquid on the plug.
- This toothbrush contains a built-in rechargeable battery, and should never be exposed to fire, nor charged, used, or stored in a high-temperature environment.
- Do not hit or drop the toothbrush. If it is damaged due to impact or dropping, stop using it.
- Do not attempt to modify, disassemble or repair the toothbrush by yourself.
- Use a charger complying with IPX4 or above only for charging.

⚠Precautions

- Check the toothbrush for obvious damage before using it. Do not use it if it is severely damaged.
- Make sure the local power supply's voltage matches the rated voltage input of the toothbrush's power adapter, before plugging it in.
- Do not use the charging dock outdoors in direct sunlight.
- Do not use the toothbrush while bathing or showering.






- Do not share the brush head with others.
- Do not wrap the power cord around the charging dock while it is plugged into an outlet.
- Do not place any metal objects on top of the charging dock while it is plugged into an outlet.

Note: Illustrations of the product, accessories, and user interface in the user manual are for reference purposes only. The actual product and functions may vary due to product enhancements.

CE

Hershey, SOOCAS (Shenzhen) Technology Co., Ltd., declares that the radio equipment type MESS01 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <http://www.mi.com/global/service/support/declaration.html>

All products bearing this symbol are waste electrical and electronic equipment (WEEE) as in directive 2012/19/EU which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points.



Scan the QR code to download and install the app. You will be directed to the connection setup page if the app is installed already. Or search "Mi Home/Xiaomi Home" in the app store to download and install it. Open Mi Home/Xiaomi Home app, tap "+" on the upper right, and then follow prompts to add your device.

The app is referred to as Xiaomi Home app in Europe (except for Russia). The name of the app displayed on your device should be taken as the default.

workwith Xiaomi Home

Note: The version of the app might have been updated, please follow the instructions based on the current app version.

Environmental Protection

When the toothbrush reaches the end of its service life, the built-in battery needs to be removed, disposed of, and recycled in accordance to local laws and regulations of the country or region it is used in.

Specifications

Name: Mi Smart Electric Toothbrush T500	Model: MESS01
Rated Voltage: 3.7 V	Rated Power: 2 W
Rated Input: 5 V-0.5 A	Charging Time: 12 hours
Maximum Output Power: 0 dBm	Battery Capacity: 700mAh
Frequency Bands: 2402-2480 MHz	IP Rating: IPX7
Operation Frequency: 80-90 kHz (+/-25dBuA/m @ 10m)	
Brush Head Dimensions: 24.6 x 24.6 x 85.0 mm	
Toothbrush Handle Dimensions: 28.1 x 28.3 x 187.5 mm	

Charging

Toothbrush Status	Battery Level Indicator	Status	Battery Level
Using	Cyan	100%-60%	
	Orange	60%-20%	
	Red	20%-10%	
Charging	Quickly blinking red (Toothbrush cannot be turned on)	<10%	
	Cyan	100%	
	Slowly blinking cyan	100%-60%	
	Slowly blinking orange	60%-20%	

The charging dock of the toothbrush is designed for the T500 and is not compatible with other products.

When the battery is low, the indicator is quickly blinking red, and the toothbrush cannot be turned on. It takes about 10 to 16 hours to fully charge the toothbrush.

When the toothbrush is in charging, connecting it with the app will turn the battery level indicator into blinking blue three times. After successfully connected, the indicator of the toothbrush stays blue. It will automatically disconnect with the app after your data completing synchronization, and the indicator of the toothbrush will display the current battery level. In case the toothbrush fails to connect with the app, the indicator stays unchanged, that is displaying the current battery level.

Troubleshooting

Issue	Possible Causes	Solutions
Unable to turn on by pressing button	Charging Bluetooth is connected Battery level is too low	Remove the toothbrush from the charging dock Disable the Bluetooth of your phone Place the toothbrush on the charging dock to charge
Unable to install the brush head onto the shaft	There is something stuck inside the brush head There is something stuck on the shaft Not a genuine brush head	Use a tool to remove the object from the brush head Clean the shaft Replace it with a genuine brush head
Excessive power consumption and charging frequently	Paired to the phone via Bluetooth for a long time Used too frequently	Disable Bluetooth when not using the toothbrush Place the toothbrush on the charging dock to charge
Brush head vibration is weak	Brush head is not installed properly There is something stuck between the brush head and the handle	Reinstall the brush head Remove the brush head and remove the object
Unable to connect to the app	The Bluetooth of your phone is not enabled Toothbrush is too far away from the phone Toothbrush is vibrating	Enable the Bluetooth of your phone and control it via the Mi Home app/Xiaomi Home app Place the phone near the toothbrush Turn off the toothbrush and try to connect again